

### Manual

DVS050 DVS100 DVS170 DVM050 DVM100 DVM170



# **VISION Spectra**

welldana

23-09-21

### **Table of contents**

Technical specifications	Page 4
Remarks	Page 5
Box contents	Page 6
Installation instructions	Page 7-8-9
Wiring instructions setup 1	Page 10-11
Wiring instructions setup 2	Page 12-13
Retrofit in PAR56 niche (only Vision Spectra 170mm)	Page 14
Color programs	Page 15
Synchronizing & color changing	Page 16
Color locking	Page 17
Troubleshooting	Page 18



### **Technical specifications**

Maximum input voltage: **14 VAC 50 Hz** (at lamp terminals)

Lamp Type	Description	Volta	ige	Power	Color temp	Luminous flux*	
DVS050-RGB DVS050-TW DVS050-WH DVM050-WH	RGB color 50mm Tunable white 50mm Day white 50mm Low Day white 50mm	10-14 10-14 10-14 10-14	VAC	8 W 8 W 10 W 5 W	All colors 2000-17500K 5000K 5000K	450 lm 550 lm 700 lm 375 lm	
DVS100-RGB DVS100-TW DVS100-WH DVM100-WH	RGB color 100mm Tunable white 100mm Day white 100mm Low Day white 100mm	10-14 10-14 10-14 10-14	VAC	20 W 20 W 26 W 9 W	All colors 2000-17500K 5000K 5000K	1550 lm 1500 lm 2300 lm 875 lm	
DVS170-RGB DVS170-TW DVS170-WH DVM170-WH DVM170-RGB	RGB color 170mm Tunable white 170mm Day white 170mm Low Day white 170mm Low RGB color 170mm	10-14 10-14 10-14 10-14 10-14	VAC VAC VAC	32 W 32 W 40 W 17 W 20 W	All colors 2000-17500K 5000K 5000K All colors	2450 lm 2400 lm 3950 lm 1675 lm 1600 lm	
(*) Propulsion systems remains a tolerance of +/- 10% on luminous flux measurements @ 25°C ; 12VAC							
For operation only with a safety isolation transformer				VIII IEC Protection Class III Operation on DC voltages is NOT allowed			
Minimum input (at lamp terminals			•		r temperature:	+40°C	
Nominal input v (at lamp terminals	voltage: 12 VAC 50 Hz					Lamps have to out of ice zone	

Ingress protection rate:

o be kept nes

#### **IP68** measured at 3m max depth = 3m

#### Remarks

#### Water conditions

Prevent damage to your pool lamps and wires due to unstable water conditions. Your local government may have enacted guidelines for your pool water conditions to apply by. If not we strongly advise the following parameter specifications to be applied:

pH level	6,8 - 7,6
Free Chlorine	max. 3ppm
Combined chlorine	max. 1 ppm
Water temperature	max $+40^{\circ}$ C and lamps need to be kept out of ice zones

Always adhere to the instructions provided by your chemical brand/supplier for the correct use and application of pool chemicals.

Salt water pools, or pools fitted with a salt water chlorine generator contain salt in the pool water. Salt is a corrosive material. Overdosage and/or consistent levels of salt increase the possibility of deterioration of your pool lamps and cables. As a rule of thumb, a concentration of 35gr/l salt can be accepted when pH values are between 7,2-7,4. In any case, we urge proper use, care and maintenance of your installation, in order to minimize the effect of corrosion and deterioration.

Please be aware that pool lamps and cables with defects caused due to abnormalities in the water condition are not covered by our factory warranty.

#### Installation/maintenance

The luminaire is maintenance free

If the luminaire needs to be replaced, it needs to be completely removed from the water



If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid hazard



Vision Spectra Pool lamps must be completely submerged into water during operation. Fixing the lamps with adhesives or silicone kit into a niche is not allowed Not following these instructions, will void warranty.

### **Box contents**



Vision Spectra lamp (50,100 or 170 mm)




2m Cable (2x1mm²)




(only for 170mm models)


Connection Kit Vision Spectra ( 513-0228 )







#### **Connector installation**












### Wiring instructions Setup 1

#### For new installations

Each lamp is connected to the transformer by a separate cable



		CABLE	SECTIO				
	LAMP TYPE	1,5mm²	2,5mm²	4,0mm <sup>2</sup>	6,0mm²	10mm²	VA TRANSFORMER (12VAC)*
0	DVS050-TW DVS050-RGB DVS050-WH	75m	125m	200m	300m	500m	13 VA
$\bigcirc$	DVM050-WH	150m	250m	400m	600m	1000m	7 VA
$\bigcirc \overset{\diamond}{>}$	DVS100-TW DVS100-RGB DVS100-WH	25m	45m	75m	115m	195m	34 VA
0	DVM100-WH	85m	140m	200m	300m	550m	12 VA
$\bigcirc \overset{\diamond}{\bigcirc}$	DVS170-TW DVS170-RGB DVS170-WH	20m	30m	50m	75m	125m	52 VA
$\bigcup \circ$	DVM170-WH	45m	75m	120m	180m	300m	22 VA
0	DVM170-RGB	35m	60m	100m	150m	250m	26 VA

### STABLE OPERATION OF THE POOL LIGHTS IS ONLY GUARANTEED WHEN THE INSTALLED CABLE CROSS SECTION MATCHES OR EXCEEDS THE ADVISED VALUES IN THE ABOVE TABLE


\* The transformer VA rating must be greater or equal to the sum of VA ratings of all connected lamps. These cable lenghts are calculated with worst case voltage drops in the electrical wiring.

11

### Wiring instructions Setup 2

#### For existing or other installations

All lamps are connected to the transformer via 1 cable



– – – 2m cable included in lamp package
— Separate cable ( not included )




		SELECT CABLE SECTION & MAXIMUM LENGTH					
	LAMP TYPE	QTY	2,5mm <sup>2</sup>	4,0mm²	6,0mm²	10mm <sup>2</sup>	VA TRANSFORMER (12VAC)
	DVS050-TW DVS050-RGB DVS050-WH	1 2 3 4	125m 63m 42m 31m	200m 100m 67m 50m	300m 150m 100m 75m	500m 250m 167m 125m	13 26 39 52
$\mathbf{v}$	DVM050-WH	1 2 3 4	250m 125m 83m 63m	400m 200m 133m 100m	600m 300m 200m 150m	1000m 500m 333m 250m	7 14 21 28
	DVS100-TW DVS100-RGB DVS100-WH	1 2 3 4	45m 23m 15m 11m	75m 38m 25m 19m	115m 58m 38m 29m	195m 98m 65m 49m	34 68 102 136
$\cup_{\circ}$	DVM100-WH	1 2 3 4	140m 70m 47m 35m	200m 100m 67m 50m	300m 150m 100m 75m	550m 275m 183m 138m	12 24 36 48
8	DVS170-TW DVS170-RGB DVS170-WH	1 2 3 4	30m 15m 10m 8m	50m 25m 17m 13m	75m 38m 25m 19m	125m 63m 42m 31m	52 104 156 208
$\bigcirc$	DVM170-WH	1 2 3 4	75m 38m 25m 19m	120m 60m 40m 30m	180m 90m 60m 45m	300m 150m 100m 75m	22 44 66 88
0	DVM170-RGB	1 2 3 4	60m 30m 20m 15m	100m 50m 33m 25m	150m 75m 50m 38m	250m 125m 83m 63m	26 52 78 104

STABLE OPERATION OF THE POOL LIGHTS IS ONLY GUARANTEED WHEN THE INSTALLED CABLE CROSS SECTION MATCHES OR EXCEEDS THE ADVISED VALUES IN THE ABOVE TABLE

### Retrofit in PAR56 niche (only Vision Spectra 170mm)







### **Color programs**

### RGB LAMPS

1	CANDLE LIGHT
2	WARM WHITE
3	NEUTRAL WHITE
4	COLD WHITE
6	CARIBEAN BLUE
6	BLUE
7	GREEN
8	RED
9	PURPLE
10	YELLOW DYNAMIC
1	BLUE DYNAMIC

2000K very warm white			
3000K warm white			
5000K neutral white			
9500K cold white			
cyan			
blue			
green			
red			
purple			
slow animation yellow			
fast animation blue			

### TW LAMPS

1 CANDLE LIGHT	2000K
<b>2</b> WARM WHITE	3000K
<b>3</b> NEUTRAL WHITE	5000K
4 COLD WHITE	9500K
<b>5</b> BLUE-WHITE	13500K
6 COOL BLUE	17500K

### Synchronizing & color changing (for RGB and TW lamps only)

#### Manual synchronization

- 1. Switch ON the 12 VAC line voltage and make sure that all lamps light up.
- 2. Switch OFF the 12 VAC line voltage and wait for at least 20 sec (max 60 sec)
- 3. Switch ON and switch OFF (max 3 sec ON and max 3 sec OFF)
- 4. Switch ON and switch OFF (max 3 sec ON and max 3 sec OFF)
- 5. Switch ON
- 6. The lamps should now all be on color program 6: Blue

\* TW lamps: the lamps will all flicker after 15 seconds on color program 6. You can now choose to lock the lamp on a desired color program by switching off/on within the next 5 seconds. After 5 seconds the flickering will stop and the lamp is locked. See next page for details.

If you did not select a color when flickering, the lamps will stop flickering after 5 seconds and the lamp will be unlocked.

#### **Changing colors**

Quickly turn the lamps OFF and back ON The lamp will jump to the next color program

#### Memorizing the actual color

Turn the lamp OFF for MINIMUM 20 seconds The last chosen color has now been memorized

### **Color Locking (only for TW lamps)**

If desired, TW lamps can be "locked" on a color program of choice. This means the lamp will only light up in that specific color, and it is no longer possible to change the color program of the lamp.

This process can be reversed anytime by "unlocking" the color program. All color programs will then be available again, and can be changed at any time.

#### Locking/Unlocking procedure

Locking the color of a lamp starts with a synchronisation procedure:

- 1. Switch ON the 12 VAC line voltage
- 2. Switch OFF the 12 VAC line voltage and wait for at least 20 sec (max 60 sec)
- 3. Switch ON and switch OFF (max 3 sec ON and max 3 sec OFF)
- 4. Switch ON and switch OFF (max 3 sec ON and max 3 sec OFF)
- 5. Switch ON
- 6. Wait for about 15 seconds. The lamp(s) will now flicker
  - LOCKING: during the flickering of the lamp, select the desired color program by switching (within 5 seconds) the lamps OFF and ON quickly.
    - When the right color is selected, then wait 5 seconds, until the flickering stops
    - The lamp is now locked on the chosen color program
  - UNLOCKING: When the lamps flicker, then do nothing for 5 seconds.
    - The flickering will stop, and it is again possible to change the color program of the lamps.

### Troubleshooting

PROBLEM

. The pool light is flickering


#### SOLUTION

- 1. Switch the lamps ON and select Cold white color program
  - 2. Remove the lamp from the water, unscrew the fix nut, pull back the gasket and the black cable jacket, so you can reach the brass contacts inside the connector block (do not remove the connector block)
  - 3. Measure the voltage at the lamp terminals (while the lamp is still ON)
  - 4. The voltage at the lamp should be at least 10VAC 50Hz. If the measured line voltage is below 10VAC:
    - A. Check the output voltage at the transformator terminals. This voltage should be between 12VAC and 14VAC. Verify that the used transformator VA rating is sufficient for powering all connected lamps
    - B. If the transformator output voltage is ok, then install a thicker cable between the transformator and the lamp. (wiring instructions p. 10-13)
- In case of TW lamps: make sure the lamp is not in color locking mode
- Several pool lights in the pool show different color programs

Make sure that all lamps are connected to the same 12VAC power line. Execute the synchronization as explained on p.16

#### **Declaraction of Conformity**

Declarations of conformity covering this product are available for download from the House of Duratech website: www.duratech.be



#### **Contact details**

#### **Propulsion Systems bv**

Dooren 72 1785 Merchtem, Belgium

Tel +32 2 461 02 53

www.duratech.be info@propulsionsystems.be



## **DURAVISION**





We reserve the rights to change all or part of the contents of this document without prior notice